


# Extending Battery Life on the iPod Touch

Battery life on the iPod Touch can be depleted more rapidly while using wireless networks and accessing online content at full brightness levels

You can increase time between charges by altering a few simple settings




# Wi-Fi

Wi-Fi can be disabled when not in use by selecting **Settings** from the Home screen, and choosing **Wi-Fi** at the top of the list

Turn the switch to the **OFF** position.  
Wi-Fi is now disabled

Use the same process to turn Wi-Fi **ON** again, and rejoin the network



# Bluetooth

Like Wireless, Bluetooth can be switched off when not in use to save power

Select **General** from the Settings menu



Select **Bluetooth**

Turn the switch to the **OFF** position




# Email Settings

Frequently checking email can also drain the battery. The iPod Touch is set by default to “Push” email from a server, or “Fetch” email every 15 minutes. Reducing the frequency in checking for new mail will help prolong battery life



From the Settings menu, choose **Mail, Contacts, Calendars**.  
Choose **Fetch New Data** to access data settings

Setting the Push feature to **OFF**, and fetching email **Manually** will update email only when you access the Mail application



# Screen Brightness

Screen brightness can be reduced from the **Brightness** menu, available from the Settings screen. Set Auto-Brightness to **OFF** and select a new brightness level with the slider control to reduce battery drain



For further help and information in using the iPod Touch at the University of Worcester, please contact [eos@worc.ac.uk](mailto:eos@worc.ac.uk)

Official Apple iPod Touch documentation can be found here:  
[Apple iPod Touch Manual](#)